



SHIFT KNOB \ NON-THREADED ADAPTER INSTALLATION GUIDE

Start Here \

If you purchased a hybrid series shift knob (screw-on cover type), remove the cover from the core during this process. Install the cover when the installation process is finished.

Tools Needed \

1/8" Allen Wrench (3/32" Allen Wrench for Mini Cooper Adapters)
Side Cutter

Non-threaded Adapter Kit \

- 1 Remove the existing shift knob.
- 2 Remove the shift boot from the center console.
- 3 Slide the adapter onto the shifter arm with the threaded portion of the adapter facing up. Remove the set screws with the an allen key and place a small dab of blue Loctite on them. Lightly tighten the set screws so the adapter does not spin.

**Note ** Our adapters are precisely machined to have a tight fit to the shifter arm. Some shifter arms may require light filing or sanding to make the adapter fit.

- 4 Thread the shift knob onto the adapter until it bottoms out. If you have a shift knob with no engraving, proceed to step 5.

If you have a shift knob with engraving, loosen the set screws and rotate the adapter till the engraving pattern is lined up correctly. Tighten the set screws when you are satisfied with the engraving position.

- 5 Remove the shift knob. Fold your shift boot inside out and place the top of it over the adapter. Zip-tie the shift boot to the shoulder located below the adapter threads. Trim the zip-tie with a side cutter.
- 6 Reinstall the shift boot and the shift knob.
- 7 Test drive and enjoy your new shifting experience!